

# PREFIT

FITTINGS FOR GLASS

## Shopfitting - Handles & Door Stops





## Raising Button, Mitre Tab - 699a



		<b>ADLER®</b> brass raising button for drilled glass panel :						
			chrome	brass	satin nickel	satin brass	mat chrome	white
- A -	single, button dia. 16 mm, hole dia. 6 mm	—	—	699 08N	699 09P	—	—	
- B -	single, button dia. 26 mm, hole dia. 9 mm	699 01F	699 02G	699 05K	699 06L	—	—	
- C -	double, button dia. 26 mm, hole dia. 9 mm	699 03H	699 04J	—	—	699 10Q	699 07M	
		<b>ADLER®</b> brass closure knob. For small door. Numerous possible uses : alone, with locking stop, with magnet 640 70S, mounted on wood or on glass. For this reason, the knob is supplied without assembly screw (see 659 08Q), button dia. 20 mm Glass drilled dia. 12 mm .						
			chrome	brass	red	blue	yellow	
- D -		699 50J	699 51K	699 52L	699 54N	699 55P		
		<b>ADLER®</b> mitre tabs, self-adhesive backing, for sliding glass panel. Thickness : 3 mm.						
			chrome	white	black	silver	gold	
- E -	(H x l) 67 x 18 mm,	699 25G	699 26H	699 27J	699 28K	699 29L		
- F -	diam. 40 mm	—	699 16W	699 17X	699 18Y	699 19Z		
		<b>ADLER®</b> raising button for small door. Brass.						
			chrome	gold-plated	brass	mat chrome	white	
- G -	to bond	699 65Z	—	699 66A	699 71G	—	—	
- H -	single - hole ø 12 mm	699 67B	—	699 68C	699 73J	699 72H	699 72H	
- I -	double - hole ø 12 mm	699 69D	699 70F	—	699 75L	699 74K		


## 704 - Crystal Doorknobs



IMPORTANT : Crystal balls and half-balls are handcraft.  
 Their diameter is given with  $\pm 5$  mm tolerance.  
 The attention paid at packing does not always avoid a difference between the diameters.  
 They cannot be considered as a faulty handles.

		«Crystal Ball» doorknobs, with brass pin.					
		D	S	d	chrome	brass	
- D -		50	60	14	704 01Y	704 02Z	
- D -		60	70	14	704 03A	704 04B	
- D -		70	80	14	704 05C	704 06D	
		«Half Crystal Ball» doorknobs, with brass pin.					
		D	S	d	chrome	brass	
- E -		50	40	14	704 11K	704 12L	
- E -		60	50	14	704 13M	704 14N	
- E -		70	55	14	704 15P	704 16Q	

## 799 - Doorstops



- A -	Seal-fit brass doorstop, detachable head.	white rubber	799 03B
- B -	Doorstop with clip-on head.	white rubber black rubber	799 08H 799 10K
- C - - D - - E -	Period metal doorstop.	finish height 24 mm, diam. 28 mm height 40 mm, diam. 50 mm height 40 mm, diam. 37 mm	chrome brass 799 11L — — polished varnished brass 799 12M — — matt nickel — 799 13N — gun metal — — 799 14P
- F -	Brass stop with 2 rubber pads.	chrome	brass 799 16R 799 15D

## specifying the door opening direction

Doors can open in one of two directions :  
LH - Opening to the left  
RH - Opening to the right  
The mounting of the lock depends on this direction.

